


Thermal Analyses - 13 CCD FPA Cassegrain Optics


Jay Ambrose



Objectives - FPA Model

A

- Evaluate new FPA thermal design
- Validate appropriate radiator size
- Evaluate effect of FPA window coating/baffling
- Determine impact of specular heat exchange



Requirements

A

Requirement:

Maximum CCD operating
temp. = -80 °C

Maximum FPA window
temp. gradient = 10 °C
(TBD)

*FPA bulk temp. stability =
 ± 0.08 °C over 10 minutes


*changed to reflect smaller FPA

Derivation:

CCD EOL charge transfer
efficiency

Optics lateral color


1/350 pixel lateral motion
on CCDs




Detailed FPA Thermal Model

A

- Total number of elements = 2953
 - 523 baseplate
 - 416 CCDs
 - 623 radiator
- Steady state analysis with orbital heating on radiator
- 25% design margin on electrical heat load
 - 3.25 W CCD
 - 5.55 W filter board
- Radiator size = 0.42 m^2






Detailed FPA Thermal Model - Results



- Operating temperature requirement easier to meet due to reduced heat loads
- Elimination of FPA window coating has a substantial effect
 - heat load increase of ~ 5-6 W without reflective baffling
- Specular heat transfer (fold flat) increases heat gain from warm lens assembly by ~4-5x over diffuse, but heat load is likely smaller than baffling loads*
- Window loads can be mitigated by reflective baffling
- Baseline radiator size = 0.55 m²

*analyses performed with separate TSS radiation exchange model




Detailed FPA Thermal Model

- Baffling Sensitivity Study




- Uncoated window sensitive to baffle surfaces
- Looked at various levels of reflective surfaces on baffle and 'gaps' around fold mirror





Detailed FPA Thermal Model - Shiny Baffle/Gaps

A







Detailed FPA Thermal Model

- Black Baffle/Gaps

A






Objectives - Optics Analyses



- Evaluate thermal design for lens assembly
- Evaluate overall optics temperature distribution
- Evaluate compound mirror assembly thermal stability
- Determine impact of black-coated aperture stop on compound mirrors



Status - Optics Analyses

A

- Completed optimization of routines for simulation of proportional heater control
- Starting transient runs with full instrument/spacecraft orbital model
- Determined modifications and additional detail required for evaluation of optics temperature distribution
- Received NRL spacecraft thermal model, starting to reconcile with LM model
- Performed analyses with detailed compound mirror model and simulated aperture boundary conditions to evaluate aperture stop