



System Integration & Test

Scott Chappie

I&T Lead


NRL

202-404-2620

schappie@space.nrl.navy.mil



Top Level System I&T Flow






System Environmental Testing



- **Flight Observatory (and Flight Vehicle)**
 - **The Observatory/FV Will Undergo Vibro-Acoustic Testing at the Protoflight Level (Flight +3db for 1 Minutes/Axis)**
 - **The Observatory Will Undergo Thermal Vacuum Testing at the Protoflight Level (10°C Above & Below Design Limits)**
 - **The Observatory Will Also Undergo:**
 - **Magnetic Balance**
 - **EMI/EMC**
 - **Spin Balance/Mass Properties Determination**
 - **Pyroshock**
 - **Series of Functional & Performance Tests**
 - **Alignments Will Be Measured Pre-Test, Post Vibro-Acoustic, and Post TVAC**
- **A Test Procedure Will Be Written and Released for Each System Level Environmental Test. Procedures Will Detail:**
 - **Test Sequence, Test Levels & Tolerances**
 - **Test Article and Test Facility Configuration**
 - **Responsibilities & Success Criteria**




System Test Configurations



Observatory

Sensor Alignments
Magnetic Balance
EMI/EMC
Spin Balance
Thermal Vacuum




Flight Vehicle

Modal
Loads
Vibration
Acoustic
Pyroshock



System Test Flow




▲ = System Functional Test Performed After Completion of Test





Instrument Integration Flow



- In Addition to the Environmental Testing Performed at LM ATC, the Instrument Will Undergo a Series of Environmental (And Functional) Tests at NRL Prior to Integration With the Spacecraft:**



[illegible]





System I&T Issues



- **Balancing Contamination Control Concerns With Requirements for Spin Balancing & Demonstrating Instrument Aperture Door Operation**
 - **Current Baseline is to Open Aperture Doors a Total of Five Times During I&T Activities at NRL and KSC**
 - **At Instrument Level (At NRL)**
 1. **Manually Open (Inside Bag) for Mass Properties**
 - **At Observatory Level**
 2. **Once for Functional Testing After Instrument is Integrated With Bus**
 3. **Manually Open (Inside Bag) for Spin Balance**
 4. **Once During Observatory Level TVAC**
 - **Pre-Launch Operations at KSC**
 5. **As Part of Post-Ship/Pre-Launch Functional Testing**



Field Operations Requirements



- **Requirements for FAME Field Operations Are Captured in Following Documents:**
 - **NCST-ICD-FM002, FAME Spacecraft to Launch Vehicle Interface Requirements Document**
 - **EWR 127-1 Tailored As Detailed in NCST-D-FM010, FAME System Safety Program Plan**
 - **KHB 1710.2D, Kennedy Space Center Safety Practices Handbook**
 - **NCST-D-FM021, FAME Training and Badging Plan for KSC and Eastern Range Operations**
 - **NCST-D-FM023, FAME Field Procedure Guideline**
 - **FAME RF Plan for KSC/ER Operations**
 - **FAME Launch Site Support Plan for KSC/ER Operations**
 - **FAME Transportation Plan for KSC/ER Operations**
 - **FAME Communications Plan for KSC/ER Operations**




Field Operations Tasks



- **Field Operations Activities Are Split up in 7 Major Task Areas:**
 - **Prepare For Payload Processing**
 - **Includes Walkdown & Cleaning Payload Processing Facility (PPF), AKM Ship & Checkout, Integration of AKM & Interstage**
 - **Transport & Process Payload**
 - **Transportation of Observatory, MAGE, EAGE to KSC, Functional & Compatibility Tests, Thermal Closeouts**
 - **Prepare For Propellant Loading & AKM Mate**
 - **Prep & Loading of Servicing Carts, S/C Dry Weight**
 - **Load Propellant & Pressurant**
 - **Hydrazine and Helium Loading**
 - **Mate Spacecraft With Interstage**
 - **Installation of Clampband and Closeouts**
 - **Post Mate Processing**
 - **Wet Weight, Spin Balance, Functional & Compatibility Tests**
 - **Integrated Operations With Launch Vehicle**
 - **Activities From T-11 to Launch, Including Transport to Pad, Mate With LV, Red Tag Removal, Charging, Arming**




Field Operations Flow (1 of 2)





Field Operations Flow (2 of 2)









Field Ops Schedule (3 of 3)

[illegible]



Back-Up



Instrument Arrival at NRL

Instrument GSE

- Truck & Air Ride Trailer
- Instrument Container with Environmental Control Sys
- Instrument Purge System
- All Required GSE Shipped

- Escorts as Required

NRL GSE

- Forklift(s)
- Certified Facility Ground
- Certified Ground Cables
- Ladders
- Cleaning Equipment

Truck Arrival

- Coordinate Arrival Time
- Notify Guard Force
- Meet Truck at Gate
- Review Route to A59
- Position Trailer in A59 Receiving Area
- Wipe Down Containers as Required

In Building A59

- Personnel Briefing
- Remove Container & Crates From Truck & Place in High Bay
- Attach Facility Ground to Instrument Container
- Inspect Purge System
- Inspect All Containers/Crates
- Download Environmental Recorder, Perform Quick Look at Data
- Allow Temperature to Equalize Overnight




Unpack, Set-up, and Inspect





Post Shipment Functional Testing





Instrument Test Readiness Review



Prerequisites

- Instrument Post-Ship Functional Testing Complete
- Environmental Test Procedures Released
- Open Item Audit and Evaluation (DRs, NMRS)
- Configuration Audits (As Built Configuration List)
- Functional Test Analysis/Evaluation Complete
- Pre/Post Ship Data Compared

Test Readiness Review Team
NASA, USNO, NRL, LMMS



Instrument Mass Properties

Instrument GSE

- GN2 Purge Equipment
- Instrument Lift Fixture
- Instrument Dolly

Prerequisites

- Pre-Test Functional
- Instrument Lifting Procedure
- Flexure Hole Pattern Installed in Test Fixture
- Fixture Balanced & Indexed
- ABCL
- Test Procedure Released
- Star Trackers & Omni Mass Simulators Installed

NRL GSE

- Spin Table Fixture
- Overhead Crane
- Ground Cable
- Certified Facility Ground
- Hand Tools

In Clean Room

- Manually Open Instrument Doors
- Tape Down Bag to Instrument
- Transport Instrument on Dolly From Clean Room to Spin Balance Machine

At Spin Balance Machine

- Personnel Briefing
- Attach Instrument Lift Fixture to Crane
- Attach Lift Fixture to Instrument
- Offload Weight and Remove Dolly Attach Bolts
- Lift Instrument Off Dolly & Place on Spin Table Fixture
- Torque Flexure Bolts
- Disconnect Lift Fixture
- Maintain Purge Until Ready to Spin
- Disconnect Purge For Spins
- Reattach Purge After Spins
- Attach Instrument Lift Fixture to Crane
- Attach Lift Fixture to Instrument
- Remove Flexure Bolts
- Lift Instrument Off of Spin Table and Place on Dolly, Install Bolts
- Disconnect Lift Fixture
- Return Instrument to Clean Room

- Perform Post-Test Functional



Instrument Acoustic & Axial Vibe



Instrument GSE

- GN2 Purge Equipment
- Instrument Dolly
- Instrument Lift Fixture
- Internal Accelerometers



Prerequisites

- ABCL
- Instrument Lifting Procedure
- Test Procedure Released
- Pre-Test Functional
- Vibe Table Adapter Plate Drilled for Instrument Flexures
- Star Tracker & Omni Mass Sims Installed on Instrument
- External Accelerometers Installed Per NRL GSE Overhead Crane Procedure



NRL GSE

- Vibe Table Adapter Plate
- Certified Facility Ground
- Instrument External Accels
- Accelerometer Cables
- Hand Tools



Axial Random Vibration

- Transport Instrument From Clean Room to Acoustic Chamber
- Maintain GN2 Purge
- Personnel Briefing
- Attach Instrument Lift Fixture to Crane
- Attach Lift Fixture to Instrument
- Offload Weight & Remove Dolly Attach Bolts
- Lift Instrument Off Dolly and on to Vibration Plate
- Install and Torque Flexure Bolts
- Disconnect Lift Fixture
- Connect Accelerometer Cables, & Checkout
- Perform Test, Notch as Required to DLL



Acoustic

- Set up Acoustic Chamber for Acoustic Test
- Perform Lower Level Test & Check Responses
- Perform Full Level Test
- Attach Instrument Lift Fixture to Crane
- Attach Lift Fixture to Instrument
- Remove Flexure Bolts
- Lift Instrument Off of Vibration Plate and Place on Dolly, Install Bolts
- Disconnect Lift Fixture
- Return Instrument to Clean Room
- Perform Post-Test Functional



Instrument Lateral Vibration

Instrument GSE

- GN2 Purge Equipment
- Instrument Dolly
- Instrument Lift Fixture
- Internal Accelerometers

Prerequisites

- ABCL
- Instrument Lifting Procedure
- Test Procedure Released
- Pre-Test Functional
- Acoustic & Axial Vibe Complete
- Vibe Table Adapter Plate Drilled for Instrument Flexures
- Star Tracker & Omni Mass Sims Installed on Instrument
- **NRL GSE**
 - Internal Accelerometers
 - Overhead Crane
 - Certified Facility
- Ground
- Instrument External Accelerometers
- Hand Tools

First Lateral Axis


- Transport Instrument From Clean Room to Vibration Laboratory
- Maintain GN2 Purge
- Personnel Briefing
- Attach Instrument Lift Fixture to Crane
- Attach Lift Fixture to Instrument
- Offload Weight & Remove Dolly Attach Bolts
- Lift Instrument on to Vibration Plate
- Install and Torque Flexure Bolts
- Connect Accelerometer Cables, & Checkout
- Perform Test, Notch as Required

Second Lateral Axis

- Rotate Test Article 90°
- Verify Instrumentation
- Maintain GN2 Purge
- Install and Torque Flexure Bolts
- Perform Test, Notch as Required to DLL
- Attach Instrument Lift Fixture to Crane
- Attach Lift Fixture to Instrument
- Remove Flexure Bolts
- Lift Instrument Off of Vibration Plate and Place on Dolly, Install Bolts
- Disconnect Lift Fixture
- Return Instrument to Clean Room
- Perform Post-Test Functional




Star Tracker & Antenna Install





Instrument EMI/EMC





Test Results Review & Buyoff




Prerequisites

- Instrument Post Ship Checkout Complete
- Instrument Mass Properties, Vibro-Acoustic & EMI/EMC Testing Successfully Completed
- Environmental Test Reports Complete
- Open Item Audit and Evaluation (DRs, NMRS)
- Configuration Audits (As Built Configuration List)
- Functional Test Analysis/Evaluation Complete

Buyoff Team From
NASA, USNO, NRL, LMMS



Instrument Integration With S/C





Alignment Inspection/Verification

Instrument GSE

- GN2 Purge Equipment

Prerequisites

- Test Procedure Released
- Instrument Integration Complete (For Baseline Alignment Inspection), OR:
 - Environmental Test(s) Complete (For Post-Test Alignment Verifications)
- Rotary Table Leveled
- Theodolites Calibrated

NRL GSE


- Observatory Dolly
- Observatory Lift Fixture
- Observatory Test Adapter
- Precision Rotary Table
- Theodolites & Stands
- Vertical & Horizontal Bars
- Precision Inclinator
- Precision Tooling Plate(s)
- Certified Facility Ground
- Optical Targets
- Hand Tools
- Overhead Crane

Alignment Inspections

- Personnel Briefing
- Transport Observatory From Clean Tent to High Bay
- Maintain Instrument GN2 Purge
- Maintain Ground Connection
- Attach Observatory Lift Fixture to Crane
- Attach Lift Fixture to Observatory
- Lift Observatory Off Dolly & on to Test Adapter/Rotary Table
- Check Rotary Table Level
- Perform All Alignment Inspections Defined in Procedure
- Attach Observatory Lift Fixture to Crane
- Attach Lift Fixture to Observatory
- Lift Observatory Off Fixture & on to Dolly, Secure Clamp
- Return Observatory to Clean Tent
- Perform Post Test Functional
- Document Baseline Alignments or Compare Results to Pre-Test Inspections




Alignment Inspection Test Set-Up





Observatory Performance Test





Test Readiness Review



Prerequisites

- Observatory Pre-Environments Performance Test Complete
- Environmental Test Procedures Released
- Open Item Audit and Evaluation (DRs, NMRS)
- Configuration Audits (As Built Configuration List)
- Performance Test Analysis Complete
- Pre-Environmental Test Alignments Complete

Test Readiness Review Team

NASA, USNO, NRL, LMMS



Magnetic Balance

Instrument GSE

- GN2 Purge Equipment

Prerequisites

- TRR Successfully Completed
- Observatory to Flight Configuration
- ABCL
- Test Procedure Released
- Observatory Lifting Procedure
- Pre-Test Functional
- EAGE Checkout Performed
- NASA GFSC Portable Magnetometer Equipment Calibrated & Set Up

NRL GSE & Hardware

- Observatory Dolly
- Observatory Lift Fixture
- Observatory Test Adapter
- Magnetic Balance Dolly & Tracks
- Bus Test Adapter & Clamp
- EAGE Test Racks, Cables
- Certified Facility Ground
- Flight Balance Magnets
- Balance Magnet Holders
- Magnetometer
- Hand Tools
- Overhead Crane

Static & Dynamic Balance


- Remove Any Non-Flight Ferrous Materials From Observatory
- Personnel Briefing
- Transport Observatory From Clean Tent to New High Bay
- Maintain Instrument GN2 Purge
- Attach Observatory Lift Fixture to Crane
- Attach Lift Fixture to Observatory
- Lift Observatory Off Dolly & on to Test Adapter/Fixture
- Finish Test Set-Up Configuration
- Establish Background Readings
- Magnetic Dipole Measurement
- Balance To Fraction of Requirement
- Connect Power & Signal Cables
- Perform Power Up Sequence
- Perform Dipole Measurement
- Balance To Requirement
- Perform Power Down Sequence
- Remove Test Cables
- Attach Observatory Lift Fixture to Crane
- Attach Lift Fixture to Observatory
- Lift Observatory Off Fixture & on to Dolly, Secure Clamp
- Return Observatory to Clean Tent
- Perform Post Test Functional

Magnetic Dipole

Balance to
 ≤ 200 Pole-cm
Per Axis



EMI/EMC Testing





Spin Balance & Mass Properties



Instrument GSE

- GN2 Purge Equipment

Prerequisites

- Observatory to Flight Configuration
- ABCL
- Pre-Test Functional
- Test Procedure Released
- Observatory Lifting Procedure
- Fixture Balanced & Indexed

NRL GSE

- Observatory Test Adapter
- Observatory Dolly
- Observatory Lift Fixture
- Overhead Crane
- Certified Facility Ground
- Spin Balance Machine
- MOI Machine
- Hand Tools

In Clean Room

- Manually Open Instrument Doors
- Tape Down Bag to Instrument
- Transport Observatory on Dolly From Clean Tent to Spin Balance Machine

- Maintain Instrument Purge

At Spin Balance Machine

- Personnel Briefing
- Attach Observatory Lift Fixture to Crane
- Attach Lift Fixture to Observatory
- Lift Observatory Off Dolly & Place on Test Adapter, Install Clamp
- Disconnect Lift Fixture
- Remove Non-Flight Items (Covers)
- Maintain Purge Until Ready to Spin
- Disconnect Instrument Purge For Spins
- Reattach Purge Line After Spins
- Spin Balance to Requirement
- Move Observatory to MOI Machine
- Perform Inertia Testing
- Reinstall Protective Covers
- Attach Observatory Lift Fixture to Crane
- Attach Lift Fixture to Observatory
- Lift Observatory Off of Spin Table and Place on

Dolly, Install Clamp

- Disconnect Lift Fixture



Axial Random Vibe & Acoustic



Instrument GSE

- GN2 Purge Equipment
- Internal Accelerometers

Prerequisites

- ABCL
- Pre-Test Functional
- Test Procedure Released
- Observatory Lifting Procedure
- Engineering Model Modal Test Done
- Build Up Interstage With AKM Mass Sim
- Vibration Table Adapter Plate Drilled For FV Test Adapter, PAF Bolted Down
- Accelerometers Installed Per Procedure

IRIGSE & Hardware

- PAF GSE Test Racks, Cables
- Observatory Dolly
- Observatory Lift Fixture
- Flight Vehicle Test Adapter (PAF)
- AKM Mass Simulator
- Flight Interstage
- Overhead Crane
- Certified Facility Ground
- Vibration Table Adapter Plate
- Accelerometers & Cables
- Hand Tools

Axial Random Vibration


- Transport Observatory From Clean Tent to Acoustic Chamber
- Maintain Inst GN2 Purge
- Personnel Briefing
- Attach Observatory Lift Fixture to Crane
- Attach Lift Fixture to Observatory
- Lift Observatory Off Dolly and on to Interstage
- Install S/C Marmon Clamp
- Lift Flight Vehicle on to PAF
- Boeing Personnel Install Delta Clampband
- Disconnect Lift Fixture, Remove From Chamber
- Connect Accelerometer Cables, & Checkout
- Connect EAGE Cables
- Remove Non-Flight Covers
- Power Up Functions Active at Launch
- Perform Test, Notch as Required to DLL

Acoustic


- Set up Acoustic Chamber for Acoustic Test
- Perform Lower Level Test & Check Responses
- Power Up Functions Active at Launch
- Perform Full Level Test
- Perform Post Test Functional
- Power Down Sequence
- Reinstall Protective Covers
- Attach Observatory Lift Fixture to Crane
- Attach Lift Fixture to Flight Vehicle (FV)
- Unbolt PAF From Plate
- Lift FV + PAF Off Vibration Plate and Place on Dolly, Install Bolts
- Disconnect Lift Fixture
- Transport FV to Main Vibration Laboratory
- Maintain Instrument



Axial & Lateral Vibe Set-Up



Axial Vibration Test Set-Up



**FAME Flight Vehicle Lateral
Axes Vibration Test Set-Up**



Lateral Random Vibration



Instrument GSE

- GN2 Purge Equipment
- Internal Accelerometers



Prerequisites

- Axial Vibe & Acoustic Tests Done
- ABCL
- Pre-Test Functional
- Test Procedure Released
- Observatory Lifting Procedure
- Vibration Table Adapter Plate Drilled For FV Test Adapter (PAF)
- Accelerometers Installed Per Procedure
- EAGE Checkout Performed
- FV Attached to PAF With Clampan



NRL GSE

- EAGE Test Racks, Cables
- Observatory Dolly
- Observatory Lift Fixture
- Overhead Crane
- Certified Facility Ground
- Vibration Table Adapter Plate
- Accelerometers & Cables
- Hand Tools



First Lateral Axis

- Maintain Instrument Purge
- Maintain Ground Connection
- Personnel Briefing
- Attach Observatory Lift Fixture to Crane
- Attach Lift Fixture to FV
- Lift FV/PAF Off Dolly and on to Vibration Adapter Plate
- Install PAF Hold Down Bolts
- Disconnect Lift Fixture
- Connect Accelerometer Cables & Checkout
- Connect EAGE Cables
- Remove Non-Flight Covers
- Power Up Functions Active at Launch
- Perform Test, Notch as Required to DLL
- Perform Post Test Functional
- Power Down Sequence
- Install Protective Covers



Second Lateral Axis

- Maintain Instrument Purge
- Maintain Ground Connection
- Personnel Briefing
- Attach Observatory Lift Fixture to Crane
- Attach Lift Fixture to FV
- Remove PAF Bolts
- Lift FV/PAF and Rotate 90° to Vibration Adapter Plate
- Install PAF Hold Down Bolts
- Disconnect Lift Fixture
- Verify Instrumentation
- Remove Non-Flight Covers
- Power Up functions Active at Launch
- Perform Test, Notch as Required to DLL
- Perform Post Test Functional
- Power Down Sequence
- Install Protective Covers



Pyroshock

Instrument GSE

- GN2 Purge Equipment
- Internal Accelerometers

Prerequisites

- Vibration & Acoustic Tests Done
- ABCL
- Pre-Test Functional
- Test Procedure Released
- Observatory Lifting Procedure
- Accelerometers Installed Per Procedure
- Boeing Delta Personnel Support
- NRL Safety Review & Support
- EAGE/OCS Rack Checkout Performed
- Observatory Attached to Interstage

- With Flight Marmon Clamp
- FV Attached to PAF With Clampband
 - EAGE Test Racks, Cables
 - Ordnance Checkout

Equipment

- Ordnance Firing Equipment
- Observatory Dolly
- Observatory Lift Fixture
- Overhead Crane
- Certified Facility Ground
- Vibration Table Adapter Plate
- Accelerometers & Cables
- Hand Tools

In A59 Vibration Lab

- Notify NRL Safety Office of Pending Ordnance Activities, Brief Personnel
- Maintain Instrument Purge
- Maintain Ground Connection
- Verify Instrumentation
- Attach Hydraset & Observatory Lift Fixture to Crane
- Place Extra Cover Over Observatory
- Attach Lift Fixture to Observatory
- Use Hydraset to Offload Flight Vehicle Weight
- Power up Functions Active at Separation
- Actuate Delta Clampband
- Separate FV From PAF Enough to Activate Separation Switches
- Set FV Back Down on PAF & Reinstall Clampband
- Use Hydraset to Offload Observatory Weight
- Actuate Interstage to Observatory Marmon Clamp Ordnance
- Separate Observatory from Interstage Enough to Activate Separation Switches

Perform Post Test Functional

- Power Down Sequence



Thermal Vacuum



Instrument GSE

- Instrument Purge



Prerequisites

- Vibe & Acoustic Completed
- Post Vibro-Acoustic Alignments Complete
- ABCL, Bus Prev. Baked Out
- Pre-Test Functional
- Test Procedure Released
- Chamber Pre-Conditioned
- Observatory Lifting Procedure



NRL GSE

- Chamber Trolley Drilled to Accept TVAC Test Adapter
- EAGE Test Racks,

Cables

- Observatory Dolly
- Observatory Lift Fixture
- Observatory Test Adapter
- Certified Facility Ground
- Chamber Trolley & Plate
- Chamber Test Cables
- Cold Plates
- Thermocouples
- Thermocouple Test

Test Set-Up


- Install Test Thermocouples on Observatory in Clean Tent
- Attach Test Cables to Observatory
- Chamber Test Plate is on Trolley, Under Crane Footprint
- Transport Observatory From Clean Tent to TVAC Test Trolley
- Maintain Instrument GN2 Purge
- Maintain Ground Connection
- Personnel Briefing
- Attach Observatory Lift Fixture to Crane
- Attach Lift Fixture to Observatory
- Lift Observatory Off Dolly and on Test Adapter/Chamber Test Plate
- Install Marmon Clamp
- Disconnect Lift Fixture
- Remove Protective Covers
- Roll Trolley to Chamber & Install Plate in Chamber
- Set Up Cold Plates (as

TVAC Test

- Remove Instrument Bags
- Close Door, Repeat Functional
- Pull Vacuum, Perform Ambient Temperature Functional Test
- Go Hot With FPA Heaters on (Drive off H2O & Volatiles)
- Monitor TQCM & RGA, Proceed With Test When Outgassing Rate is Acceptable
- Perform 4 Thermal Cycles with Performance or Functional Test at Each Extreme
- At Appropriate Time, Deploy Instrument Aperture Covers
- Warm up Test Article From Last Cold Cycle
- Back Fill Chamber With Dry Nitrogen, Open Door
- Close Instrument Aperture Doors
- Attach Instrument Purge
- Perform Post Test Functional
- Remove Test Plate From




Observatory in TVAC Chamber






Mission Simulation






RF End-to-End Compatibility





Post Environments Performance





Pre-Ship Readiness Review




Prerequisites

- Observatory Verifications/Buy Off Complete
- Environmental Testing Complete
- Open Item Audit and Evaluation (DRs, NMRS)
- Configuration Audits (As Built Configuration List)
- Complete Full Functional Analysis Complete
- Post-Environmental Test Alignments Complete
- Transportation Plan Complete & Released

Pre-Ship Review Team
NASA, USNO, NRL, LMMS




Prep and Ship to KSC





FAME in Shipping Container



- **FAME Observatory Easily Fits Inside XTE/TRMM/MAP Shipping Container**
 - **Approximately 15 Inches of Lateral Clearance (Each Side)**
 - **Plenty of Height Available for Adapter and Shock Isolators**